

WEBSERVER	WEBSERVER Settings		
	IP Address ^[1]	Subnet Mask ^[1]	Default Gateway ^[1]

"Physical" or "Virtual" GATEWAY	Network Settings			Bus Modbus RS485 Settings (Only for "Physical" Gateways)					Settings			
	IP Address ^[1]	Subnet Mask ^[1]	Default Gateway ^[1]	Mode ^[1]	Parity ^[1]	Stop Bits ^[1]	Speed ^[1]	Timeout RS485 ^[1]	Name ^[1]	Description / Location	Panel Board	EQ Device

Note: max. 32 Modbus addresses or Pulse counters for each Gateway. In case of several Gateways, use a parameter table for each gateway.

DEVICE	"Physical" or "Virtual" DEVICE Settings											
No.	Model ^[1]	Modbus Address ^[1] (Modbus Address-Position ^[2]) (247-Virtual device type ^[5])	Name ^[1]	Supply ^[4]	Exclude from totals ^[3]	CT Ratio (ex. .../5A or .../1A)	Load	Measure Group 1	Measure Group 2	Measure Group 3	Measure Group 4	Measure Group 5
1												
2												
3												
4												
5												
6												
7												
8												
9												
10												
11												
12												
13												
14												
15												
16												
17												
18												
19												
20												
21												
22												
23												
24												
25												
26												
27												
28												
29												
30												
31												
32												

Details for Pulse Output Meters		
Model ^[1]	Modbus Address ^[1]	Position ^[2]
Counter model	Modbus address of the Concentrator	Corresponds at the input number of the Concentrator on which the counter is connected!

Details for "Exclude from totals" ^[3]
Use this option if you want that consumptions of the selected device is not included in the pages "Total" and "Partial" of the menu "Consumption." This consumptions will always be displayed on the page "Details".

Details for NEMO SX Measure Devices
Supply ^[4]
To ensure correct measurement of various electrical quantities, it is necessary to indicate the Supply direction of the protection device: - device supplied from the top → Upstream - device supplied from the bottom → Downstream

Details for Master/Slave function ^[5]
Modbus Address (<u>fixed value equal to 247</u>) - Indication of the virtual device type: 247 - 1XXXX = Positive active energy of the Device with ID = XXXX 247 - 2YYYY = Positive active energy of the Load with ID = YYYY 247 - 3ZZZZ = Positive active energy of the Measure Group with ID = ZZZZ 247 - 29999 = Total Positive active energy of all Electrical Loads

LEGEND
^[1]Required Parameters
^[2]Required Parameter only for Pulse Output Meters
^[3]Optional parameter only for measuring devices
^[4]Required Parameter for NEMO SX

NOTE: for more details refer to the user manual

